

Luxor	5639	SX9 Chassis
Luxor	5644	SX9 Chassis
Luxor	5661	A-1 CHASSIS
Luxor	5664	A-1 CHASSIS
Luxor	5681	B-1 CHASSIS
Luxor	5691	B-2 Chassis
Luxor	5698	B-2 Chassis
Luxor	6355	SX9 Chassis
Luxor	6368	K-1 Chassis
Luxor	6385	M Chassis
Luxor	6387	L-2 CHASSIS
Luxor	6615	A-2 CHASSIS
Luxor	6656	SX9 Chassis
Luxor	6661	A-1 CHASSIS
Luxor	6663	A-1 CHASSIS
Luxor	6664	A-1 CHASSIS
Luxor	6709	B-2 Chassis
Luxor	6711	B-2 Chassis
Luxor	6711	BC Chassis
Luxor	6714	A-2 CHASSIS
Luxor	6718	B-2 Chassis
Luxor	6718	BC Chassis
Luxor	6719	A-2 CHASSIS
Luxor	6734	SX9 Chassis
Luxor	6736	SX9 Chassis
Luxor	6739	SX9 Chassis
Luxor	6741	SX9 Chassis
Luxor	6781	A-1 CHASSIS
Luxor	6791	B-2 Chassis
Luxor	6798	B-2 Chassis
Luxor	7064	L-2 CHASSIS
Luxor	7068	K-1 Chassis
Luxor	7075	M Chassis
Luxor	7076	M-1 CHASSIS
Luxor	7085	M Chassis
Luxor	7128	EURODIGI 16:9
Luxor	8228	EURODIGI 16:9
Luxor	9128	EURODIGI 16:9
Luxor	18056449	SX9 Chassis
Luxor	18067349	SX9 Chassis
Luxor	17L67	L2 Chassis
Matsui	1091	
Matsui	1402	
Matsui	1403	
Matsui	1410	Saisho CT142R
Matsui	1410	Amstrad CTV1401
Matsui	1420	Orion 14DS
Matsui	1422	
Matsui	1424	TATUNG 190/195
Matsui	1430	
Matsui	1436	Bush 2004
Matsui	1436	
Matsui	1440	Orion 14DR
Matsui	1450	Saisho CT147R
Matsui	1450	Binatone 01/9014

Matsui	1455	Alba CTV4805
Matsui	1465	
Matsui	1466	ORION 14LR
Matsui	1476	
Matsui	1480	Saisho CT149
Matsui	1482	
Matsui	1498	Onwa
Matsui	1580	Bush 2020
Matsui	1640	Orion 16BR
Matsui	1810	Orion 18PS
Matsui	1820	
Matsui	2080	Saisho CT149TX
Matsui	2086	Onwa
Matsui	2090	GOLDSTAR CT2190
Matsui	2091	Goldstar CIT2181FG
Matsui	2098	Onwa
Matsui	2160	Saisho FST210R
Matsui	2185	
Matsui	2190	11AK02
Matsui	2199	
Matsui	2220	Toshiba 221E4B
Matsui	2580	11AK02
Matsui	2890	Saisho CM2880TX
Matsui	6091	
Matsui	6092	
Matsui	1420	
Matsui	1420A	Saisho CT141X
Matsui	1420A	Saisho CT141X
Matsui	1420A	
Matsui	1420B	
Matsui	1424	
Matsui	1430A	
Matsui	1435B	
Matsui	1436XA	
Matsui	1440A	Saisho CT142RX
Matsui	1440A	Saisho CT142RX
Matsui	1460 1660 2060	
Matsui	1480A	Orion 14DT
Matsui	1480A	Saisho CT149TX
Matsui	1480B	
Matsui	1481	
Matsui	1481B	
Matsui	1481B	
Matsui	14R1	GrundigG1000
Matsui	14T1	GrundigG1000
Matsui	14V1R	GrundigCUC7301
Matsui	14V1T	GrundigCUC7301
Matsui	2074 2086	BUSH 2002,2052T
Matsui	2074R	
Matsui	2076R	
Matsui	2086	
Matsui	2086T	
Matsui	2091	PC-04A
Matsui	2092T	
Matsui	2095T	

Matsui	209T	
Matsui	20R1	Grundig G1000
Matsui	20T1	Grundig G1000
Matsui	20V1R	Grundig CUC7301
Matsui	20V1T	Grundig CUC7301
Matsui	20V1T	Grundig CUC7301/3
Matsui	2150TX	
Matsui	2160	
Matsui	2180TT	Saisho FST212T
Matsui	2180TT	
Matsui	2190	Saisho FST2130TX
Matsui	21N1	Grundig G1000ST
Matsui	21V1N	Grundig CUC7350
Matsui	2580 2590	
Matsui	2590	Saisho FST2530TX
Matsui	25M1	EB2-1
Matsui	25M1 Mk 2 & Mk 3	EB4A
Matsui	28M1	EB2-1
Matsui	28M1 Mk2 & Mk 3	EB4A
Matsui	CM260	Fidelity ZX5000
Matsui	CT20S	Panasonic U4W
Matsui	CT22S	Panasonic U4W
Matsui	CTV2055	Jackson 20R
Matsui	CTV8510	Toshiba C223B1
Matsui	RD6000	OMNI
Mitsubishi	BB1201	Mono
Mitsubishi	BB1207	Mono
Mitsubishi	C28C7B	EE3 Chassis
Mitsubishi	CP140	
Mitsubishi	CP1424	
Mitsubishi	CT1SMS1TX	EE2 Chassis
Mitsubishi	CT1447	Euro 3 Chassis
Mitsubishi	CT14MS1	
Mitsubishi	CT1525	
Mitsubishi	CT1535	EURO7
Mitsubishi	CT15M2T	EURO7
Mitsubishi	CT15M2TX	EURO7
Mitsubishi	CT180	
Mitsubishi	CT186	
Mitsubishi	CT1902	
Mitsubishi	CT1905	
Mitsubishi	CT2023	
Mitsubishi	CT2027	
Mitsubishi	CT2027	
Mitsubishi	CT2101	
Mitsubishi	CT2117	
Mitsubishi	CT2124	Euro 4 Chassis
Mitsubishi	CT2125	
Mitsubishi	CT2131	Euro 4 Chassis
Mitsubishi	CT2132	Euro 4 Chassis
Mitsubishi	CT2141	Euro 4 Chassis
Mitsubishi	CT2142	Euro 4 Chassis
Mitsubishi	CT2144	Euro 4 Chassis
Mitsubishi	CT2145	Euro 6 Chassis
Mitsubishi	CT2145BM	Euro 6 Chassis

Mitsubishi	CT2146	Euro 6 Chassis
Mitsubishi	CT2146TX	Euro 6 Chassis
Mitsubishi	CT2153	
Mitsubishi	CT2154	Euro 4 Chassis
Mitsubishi	CT21553	
Mitsubishi	CT21A2	Euro 12 Chassis
Mitsubishi	CT21A2LS	Euro 12 Chassis
Mitsubishi	CT21A2S	Euro 12 Chassis
Mitsubishi	CT21A2ST	Euro 12 Chassis
Mitsubishi	CT21A3	
Mitsubishi	CT21A3ST	A3
Mitsubishi	CT21A5	E14FS
Mitsubishi	CT21A5STX	E14FS
Mitsubishi	CT21ASTX	Euro 12 Chassis
Mitsubishi	CT21AV1B	AV1
Mitsubishi	CT21M1	M1 Chassis Euro 10 Chassis
Mitsubishi	CT21M1BM	M1 Chassis Euro 10 Chassis
Mitsubishi	CT21M1LM	M1 Chassis Euro 10 Chassis
Mitsubishi	CT21M2	
Mitsubishi	CT21M3	
Mitsubishi	CT21M5BT	EE4 Chassis
Mitsubishi	CT21M5B	M5
Mitsubishi	CT2206	
Mitsubishi	CT2217	
Mitsubishi	CT2223	
Mitsubishi	CT2224	
Mitsubishi	CT2227	
Mitsubishi	CT2230	
Mitsubishi	CT2517	Euro 1 Chassis
Mitsubishi	CT2525	Euro 10 Chassis
Mitsubishi	CT2528	Finlux 9000
Mitsubishi	CT2531	Euro 4 Chassis
Mitsubishi	CT2532	Euro 4 Chassis
Mitsubishi	CT2533	
Mitsubishi	CT2534	Euro 4 Chassis
Mitsubishi	CT2545	Euro 4 Chassis
Mitsubishi	CT2553	Euro 4Z Chassis
Mitsubishi	CT2554	
Mitsubishi	CT2555	
Mitsubishi	CT25A2	Euro 12 Chassis
Mitsubishi	CT25A2ST	A2
Mitsubishi	CT25A3ST	A3
Mitsubishi	CT25A4	Euro 12 Chassis
Mitsubishi	CT25A4ST	A4
Mitsubishi	CT25A5	E14FS
Mitsubishi	CT25A5ST	E14FS
Mitsubishi	CT25A6ST	A2
Mitsubishi	CT25AV1	AV1
Mitsubishi	CT25AV1B	AV1
Mitsubishi	CT25AV1BDS	EE3 Chassis
Mitsubishi	CT25B2ST	B2
Mitsubishi	CT25B2STX	Euro 12 Chassis
Mitsubishi	CT25B3ST	B3
Mitsubishi	CT25M1	M1 Chassis Euro 10 Chassis
Mitsubishi	CT25M5	

Mitsubishi	CT25M5B	M5
Mitsubishi	CT2627	
Mitsubishi	CT28AV1	AV1
Mitsubishi	CT28AV1B	AV1
Mitsubishi	CT28BW2B	EE3 Chassis
Mitsubishi	CT2964	Euro 4Z Chassis
Mitsubishi	CT2965	Euro 8F Chassis
Mitsubishi	CT29A4	Euro 12 Chassis
Mitsubishi	CT29A4ST	A4
Mitsubishi	CT29A6ST	A6
Mitsubishi	CT29AT5	
Mitsubishi	CT29B2	Euro 12 Chassis
Mitsubishi	CT29B2ST	B2
Mitsubishi	CT29B3	
Mitsubishi	CT29B3ST	B3
Mitsubishi	CT29B4ST	B4
Mitsubishi	CT33B3ST	B3
Mitsubishi	CT33C1	
Mitsubishi	CT37C1	
Murphy	3510T	Goodmans FST51TT
Murphy	CTV 3510	Murphy CTV 3540T
Murphy	CTV3500	Cathay/Osaki P22G
Murphy	CTV3540T	Goodmans FST51TT
Murphy	M14R01	Fidelity ZX4000
Murphy	M1500	Fidelity ZX4000
Murphy	M22S01	Fidelity ZX4200
Murphy	M22S01	Fidelity ZX4200
Murphy	M22T01	Fidelity ZX4000
Murphy	MC6124	Bush BC6004
NEI	1288	Mono
NEI	1451	Indiana 100 Chassis
NEI	1461	Indiana 100 Chassis
NEI	1481	Indiana 100 Chassis
NEI	1482	Indiana 100 Chassis
NEI	1551	Indiana 100 Chassis
NEI	1581	Indiana 100 Chassis
NEI	1601	
NEI	2031	
NEI	2041	Indiana 100 Chassis
NEI	2131	Indiana 100 Chassis
NEI	2151	Indiana 100 Chassis
NEI	2181	Indiana 200 Chassis
NEI	5544	11AK03 Chassis
NEI	14FRE	
NEI	14SRE	
NEI	2051	Indiana 200 Chassis
NEI	2051R	Indiana 200 Chassis
NEI	2052R	Indiana 200 Chassis
NEI	2151	Indiana 200 Chassis
NEI	2151TX	Indiana 200 Chassis
NEI	28F1	
NEI	CTV61	Indiana 100 Chassis
NEI	E2591TFXN	CE25
NEI	NE3743TX	11AK08
NEI	NE5147	11AK03 Chassis

NEI	NE5155NT	11AK10
NEI	NE5159NT	11AK10
NEI	NE5159TX	11AK10
NEI	NE5555	11AK10
NEI	NE5559TX	11AK10
Network	1210	Similar to NEI1288
Network	1286	
Network	1401	Bush T24
Network	1402	Goldstar
Network	1410	Goldstar
Network	1414	Grundig GSC-100
Network	1430	Goldstar
Network	2020	Grundig GSC-100
Network	2081	Indiana 200 Chassis
Network	2181	Indiana 200 Chassis
Network	2571	CE25
Network	2571	CE25
Network	2591	CE25
Network	2591	CE25
Network	2871	CE25
Network	2871	CE25
Network	2891	CE25
Network	2891	CE25
Network	1451R	Indiana 100 Chassis
Network	1461R	Indiana 100 Chassis
Network	1481R	Indiana 100 Chassis
Network	1482R	Indiana 200 Chassis
Network	1551TX	Indiana 100 Chassis
Network	1581TX	Indiana 100 Chassis
Network	2031R	Indiana 100 Chassis
Network	2031TX	Indiana 100 Chassis
Network	2041R	Indiana 200 Chassis
Network	2051R	Indiana 200 Chassis
Network	2052R	Indiana 200 Chassis
Network	21311X	Indiana 200 Chassis
Network	2151R	Indiana 200 Chassis
Network	2152R	Indiana 200 Chassis
Network	E28G1TFXN	E5
Network	NW1414	Grundig GSC-100
Network	NW2020	Grundig GSC-100
Nikkai	Baby 10	Samsung C1210R / Boots CTV10R
Nikkai	Baby 10	Osaki P10R
Nikkai	BG001	
Nikkai	K3743TX	11AK08
Nikkai	K5155NT	11AK10
Nikkai	K5159NT	11AK10
Nikkai	NT14	
Nikkai	NT1416	
Nikkai	NT20	Sentra STX600
Nikkai	Tara 10	
Nikkai	TLG0101	Sentra STX600
Nikkai	TLG0909	Solarvox CML14
Nikkai	TLG100	Solarvox 142TT
Nikkai	TLG101	Hinari TVA1
Nikkai	TLG1407	Indiana 100 Chassis

Nikkai	TLG1409	
Nikkai	TLG1432	
Nikkai	TLG1433	
Nikkai	TLG1447TC	Indiana 100 Chassis
Nikkai	TLG14R	Alba CTV14R
Nikkai	TLG200	
Nikkai	TLG2000	Indiana 100 Chassis
Nikkai	TLG201	Indiana 100 Chassis
Nikkai	TLG20TX	Indiana 100 Chassis
Nikkai	TLG2121	Goodmans CTV2R
Nikkai	TLG2122	Goodmans CTV2T
Nikkai	TLG2195	
Nikkai	TLG2501	NEI CE25
Nikkai	TLG2801	NEI CE25
Nikkai	TLG511	Indiana 100 Chassis
Nikkai	TLG88/89	Osume 1484R
Nikkai	TLG88/89	Fidelity C14M07
Nikkai	TLG99	Tashiko 14F841
Nikkai	TLG99	Dansai TA11401
Nikkai	TV1407T	Indiana 100 Chassis
Nokia	3723	Luxor 4723
Nokia	3743	Luxor 4743
Nokia	3783	Luxor 4783
Nokia	1425HS	EUROP MONO 2
Nokia	1430HS	EUROMONO 1/2
Nokia	1630HS	EUROMONO 1 OR 2
Nokia	1725HS	EUROP MONO 2
Nokia	1730HS	EUROMONO 1 OR 2
Nokia	1741HS	HOTEL PLUS
Nokia	2125HS	EUROP MONO 2
Nokia	2141HS	HOTEL PLUS
Nokia	3755UK	MONOPLUS
Nokia	5155	MONOPLUS
Nokia	6364UKSFN	Eurostereo 2
Nokia	7204MAC	EURODIGI 16:9
Nokia	8284MAC	EURODIGI 16:9
Nokia	8284SAT	EURODIGI 16:9
Nokia	8294SAT	EURODIGI 16:9
Nokia	CT3711	SANYO
Nokia	CT4030UK	CORE2
Nokia	CT5111UK	CORE2
Nokia	CT5124	MONO PLUS 90DEG
Nokia	FX3725	MONO PLUS
Nokia	FX4030UK	CORE2
Nokia	FX4530UK	CORE2
Nokia	FX5530UK	CORE2
Nokia	FX5532	EUROMONO 2
Nokia	FX6332	EUROMONO
Nokia	SFN3755	MONO PLUS
Nokia	SFN5155	MONO PLUS
Nokia	SFN5166	MONO PLUS
Nokia	SFN5554	STEREO PLUS
Nokia	SFN6386	FEATURE STEREO
Nokia	SFN7186	FEATURE STEREO
Nokia	SFN7296	FEATURE STEREO PLUS

Nordmende	1444	F10
Nordmende	2112	F10
Nordmende	3434	F10
Nordmende	3601	
Nordmende	3602	F8
Nordmende	3604	F14
Nordmende	4230	FV I
Nordmende	4231	
Nordmende	5038	F15/16
Nordmende	5205	F15/16
Nordmende	5432	F11
Nordmende	6559	F15
Nordmende	7000	F15
Nordmende	8180	
Nordmende	1434PI	F10
Nordmende	2513A	F8
Nordmende	778535A	F5 TT
Nordmende	9572D	F5 TT
Nordmende	982512H	F10
Nordmende	982514/H	F10
Nordmende	982515/H	F10
Nordmende	F11B	Ferguson ICC3
Nordmende	F19	Ferguson IKC2
Nordmende	F20	Ferguson IKC2
Oceanic	B294SAT	Eurodigi 16:9
Onwa	K9228	
Orion	14DR	Matsui 1440
Orion	14DS	Matsui 1420
Orion	14DT	Matsui 1480A
Orion	14LR	Matsui 1466
Orion	14PR	Amstrad CTV1409
Orion	14PS	Amstrad CTV1401
Orion	16BR	Matsui 1640
Orion	18PS	Matsui 1810
Orion	20LS	Logik 690
Orion	20LT	Logik 698
Orion	CTV144	Saisho CX14R
Orion	CTV164	Saisho CX16R
Osaki	CI5013T	Samsung CI5052XT
Osaki	CTV14	Jackson Mk2
Osaki	P10	Nikkai Baby 10 etc
Osaki	P140	Philips GR1-AX
Osaki	P142	Akura CX4
Osaki	P145	Philips GR1-AX
Osaki	P20G	Murphy CTV3500
Osaki	P20H	Hinari CT4
Osaki	P60G	Hitachi NP8CQ
Osume	CTV1474R	Bush 2214
Osume	CTV1484R	Solarvox 141
Osume	CTV1486T	Nikkai TLG100T
Panasonic	1665	Z1
Panasonic	21V2	Alpha 4
Panasonic	25A3	Euro 1
Panasonic	25X1DP	Alpha 4
Panasonic	28X1	Alpha 4H

Panasonic	28X1DP	Alpha 4
Panasonic	CT20S	U4 Chassis
Panasonic	CT22S	U4W Chassis
Panasonic	TC1302	M6
Panasonic	TC1303	M6
Panasonic	TC1404	M11
Panasonic	TC1405	M11
Panasonic	TC1406	M11
Panasonic	TC1407	M12
Panasonic	TC1408	M12
Panasonic	TC1460	Z1
Panasonic	TC1465	Z1
Panasonic	TC1470	Z1
Panasonic	TC1475	Z1
Panasonic	TC1480	Z3
Panasonic	TC1485	Z3
Panasonic	TC14S1M	Z5
Panasonic	TC14S1R	Z5
Panasonic	TC14S2R	Z5
Panasonic	TC15M1	Z4
Panasonic	TC15M1M	Z4
Panasonic	TC15M1R	Z4
Panasonic	TC15M1T	Z4
Panasonic	TC15M2	Z4
Panasonic	TC15M2R	Z4
Panasonic	TC15M2T	Z4
Panasonic	TC15MIR	Z1
Panasonic	TC1601	M11
Panasonic	TC1602	M11
Panasonic	TC1631	U4
Panasonic	TC1632	U4
Panasonic	TC1633	U4
Panasonic	TC1635	U4
Panasonic	TC1637	U4
Panasonic	TC1641	U4
Panasonic	TC1651	U5
Panasonic	TC1665	Z1
Panasonic	TC1675	Z1
Panasonic	TC1752	U5
Panasonic	TC1785	Z3
Panasonic	TC1786	Z3
Panasonic	TC1802	M11
Panasonic	TC1802U	M7
Panasonic	TC1803	M7
Panasonic	TC1807	M9
Panasonic	TC1808	M11
Panasonic	TC1810	M11
Panasonic	TC1830	M12
Panasonic	TC1832	M12
Panasonic	TC200	M11
Panasonic	TC2000	U3
Panasonic	TC2002	U1
Panasonic	TC2006	M7
Panasonic	TC201	M9
Panasonic	TC2011	U3W

Panasonic	TC202	PIX-M9
Panasonic	TC202	M11
Panasonic	TC2020	M11
Panasonic	TC2024	U3W
Panasonic	TC202G	PIX-M9
Panasonic	TC2030	M12
Panasonic	TC2031	U4W
Panasonic	TC2033	U4
Panasonic	TC2035	M11
Panasonic	TC204	M9
Panasonic	TC2043	U4W
Panasonic	TC2051	U5
Panasonic	TC2055	M11
Panasonic	TC2056	M11
Panasonic	TC2061	U5
Panasonic	TC2076	M11
Panasonic	TC208	U3
Panasonic	TC2086	M11
Panasonic	TC210	M11
Panasonic	TC211	M12
Panasonic	TC2110	U5N
Panasonic	TC2112	U5
Panasonic	TC212	M11
Panasonic	TC214	M11
Panasonic	TC215	M12
Panasonic	TC216	M11
Panasonic	TC2160	U5N
Panasonic	TC217	M11
Panasonic	TC2175	Z1
Panasonic	TC218	M11
Panasonic	TC2185	Z3
Panasonic	TC2195	Z3
Panasonic	TC21M	Z4
Panasonic	TC21M1R	Z4
Panasonic	TC21M2R	Z4
Panasonic	TC21M2T	Z4
Panasonic	TC21R	ALPHA2
Panasonic	TC21R1	ALPHA2
Panasonic	TC21S1	Z5
Panasonic	TC21S3	Z7
Panasonic	TC220	M11
Panasonic	TC2201	U1
Panasonic	TC2202	U1
Panasonic	TC2203	U1
Panasonic	TC2204	U1
Panasonic	TC2205	U2
Panasonic	TC2206	U1/U4
Panasonic	TC2207	U2
Panasonic	TC2208	U2
Panasonic	TC2209	U3
Panasonic	TC221	U3
Panasonic	TC2210NS	M11
Panasonic	TC2210SP	M8
Panasonic	TC2210VR	M12
Panasonic	TC2211	U3W

Panasonic	TC2213	U3W
Panasonic	TC2216	U3W
Panasonic	TC222	M11
Panasonic	TC2220	M11
Panasonic	TC2221	U3
Panasonic	TC2223	U3
Panasonic	TC2225	U3
Panasonic	TC2226	U3
Panasonic	TC2229	U3
Panasonic	TC223	M12
Panasonic	TC2231	M7
Panasonic	TC2232	U4W
Panasonic	TC2233	U4W
Panasonic	TC2234	U4
Panasonic	TC2235	M11
Panasonic	TC2235UR	U4
Panasonic	TC2239	U4
Panasonic	TC224	M11
Panasonic	TC2240	U4
Panasonic	TC2243	U4
Panasonic	TC225	U3
Panasonic	TC2251	M8
Panasonic	TC2253	U5
Panasonic	TC2255	M11
Panasonic	TC2256	M11
Panasonic	TC2263	U5
Panasonic	TC2271	M8
Panasonic	TC2276	M11
Panasonic	TC2283	U2 / U3
Panasonic	TC2291	U2
Panasonic	TC2292	U2
Panasonic	TC2293	U2
Panasonic	TC230	M12
Panasonic	TC232	M12
Panasonic	TC233	M12
Panasonic	TC234	M12
Panasonic	TC235	M12
Panasonic	TC2461	U5
Panasonic	TC2475	ALPHA1W
Panasonic	TC24R1	ALPHA2
Panasonic	TC26	M11
Panasonic	TC2600	M8
Panasonic	TC2603	M11
Panasonic	TC261	M8
Panasonic	TC2610	M11
Panasonic	TC262	M7
Panasonic	TC2620	M11
Panasonic	TC2622	U3W
Panasonic	TC2629	U3
Panasonic	TC262G	M11
Panasonic	TC262GA	PIUS1
Panasonic	TC262SPM	M9
Panasonic	TC2630	M12
Panasonic	TC2633	U4
Panasonic	TC2634	U4

Panasonic	TC2635	M11
Panasonic	TC2636	U4
Panasonic	TC2637	U4
Panasonic	TC2640	U4
Panasonic	TC2641	U4W
Panasonic	TC2650	M8
Panasonic	TC2651	M8
Panasonic	TC2656	M11
Panasonic	TC265SPM	M9
Panasonic	TC2665	M11
Panasonic	TC2671	M8
Panasonic	TC2675	M11
Panasonic	TC2676	M11
Panasonic	TC2680	U2
Panasonic	TC2681	U2
Panasonic	TC2683	U3
Panasonic	TC2684	U3
Panasonic	TC2686	M11
Panasonic	TC2690	U3
Panasonic	TC271	M8
Panasonic	TC272	M8
Panasonic	TC273P	M7
Panasonic	TC273S	M9
Panasonic	TC273SP	M7
Panasonic	TC273SPM	M9
Panasonic	TC273W	M12
Panasonic	TC274	M7
Panasonic	TC275	PIX-M8
Panasonic	TC275G	PIX-M8
Panasonic	TC290	M7
Panasonic	TC292	M9
Panasonic	TC293	M7
Panasonic	TC294	M11
Panasonic	TC295	M9
Panasonic	TC296	M11
Panasonic	TC297	M9
Panasonic	TC298	M11
Panasonic	TC300SP	M6
Panasonic	TC333	PIX-M6
Panasonic	TC333G	PIX-M6
Panasonic	TC361	M7
Panasonic	TC371	PBX-M7A2
Panasonic	TC381	PIX-M6A
Panasonic	TC381G	M6
Panasonic	TC381U	M6
Panasonic	TC400	M11
Panasonic	TC410	M11
Panasonic	TC421	M11
Panasonic	TC4230	M12
Panasonic	TC430	M12H
Panasonic	TC430G	M12H
Panasonic	TC431	M12C
Panasonic	TC431GR	M12C
Panasonic	TC450	M12H
Panasonic	TC450G	M12H

Panasonic	TC4688	M12
Panasonic	TC471	M11
Panasonic	TC471NP	M7
Panasonic	TC471SP	M7
Panasonic	TC471SPM	M9
Panasonic	TC481	M6
Panasonic	TC482	M11
Panasonic	TC482S	M6
Panasonic	TC482SP	M6
Panasonic	TC4830	M12
Panasonic	TC48G	
Panasonic	TC492	PIX-M11
Panasonic	TC492G	PIX-M11
Panasonic	TC493	M11
Panasonic	TC610	M11
Panasonic	TC610SPM	M9
Panasonic	TC681MN	M12
Panasonic	TC681MRS	M12
Panasonic	TC682	PIX-M11
Panasonic	TC682GR	PIX-M11
Panasonic	TC683	M11
Panasonic	TC684	M11
Panasonic	TC685	M11
Panasonic	TC687	M12
Panasonic	TC688	M12
Panasonic	TC800	X8
Panasonic	TC810	M11
Panasonic	TC811	M11
Panasonic	TC815	M11
Panasonic	TC816	M11
Panasonic	TC817	M11
Panasonic	TC820	M11
Panasonic	TC830	M12
Panasonic	TC831	M12
Panasonic	TC85	
Panasonic	TC871	M8
Panasonic	TC872	M8
Panasonic	TC873	M8
Panasonic	TC874	M7
Panasonic	TC874SPM	M9
Panasonic	TC890SPM	M9
Panasonic	TC890W	M12
Panasonic	TC9200	U1
Panasonic	TCAL20	M11
Panasonic	TCAL26	M11
Panasonic	TCV1	M11
Panasonic	TX1	ALPHA1
Panasonic	TX1485	ALPHA1
Panasonic	TX14S1R	Z5
Panasonic	TX14S1T	Z5
Panasonic	TX14S2T	ALPHA1
Panasonic	TX15M	Z4
Panasonic	TX15M1R	ALPHA1
Panasonic	TX15M1T	Z4
Panasonic	TX15M2T	ALPHA1

Panasonic	TX15MIT	ALPHA1
Panasonic	TX1631	U4W
Panasonic	TX1632	U4
Panasonic	TX1641	U4
Panasonic	TX1642	U4
Panasonic	TX1752	U5
Panasonic	TX1786	Z3T
Panasonic	TX2	ALPHA1
Panasonic	TX2024	U3W
Panasonic	TX2034	U4
Panasonic	TX2112	U5N
Panasonic	TX211AD2	EURO2
Panasonic	TX2162	U5
Panasonic	TX2172	ALPHA1
Panasonic	TX2175	Z1
Panasonic	TX2178	ALPHA1
Panasonic	TX2195	Z3T
Panasonic	TX21AD2	EURO2
Panasonic	TX21M	Z4
Panasonic	TX21M1R	Z4
Panasonic	TX21M1T	Z4
Panasonic	TX21M2T	ALPHA1
Panasonic	TX21MD1	EURO2
Panasonic	TX21MD3	EURO2M
Panasonic	TX21S1R	ALPHA1
Panasonic	TX21S1T	ALPHA1
Panasonic	TX21S3	Z7
Panasonic	TX21T	ALPHA2
Panasonic	TX21T1	ALPHA2
Panasonic	TX21V1	ALPHA2
Panasonic	TX21V2	ALPHA4
Panasonic	TX21V2BC	ALPHA1
Panasonic	TX2200	U4
Panasonic	TX2230	U4
Panasonic	TX2231	U4
Panasonic	TX2234	U4W
Panasonic	TX2244	U4W
Panasonic	TX2284	U3W
Panasonic	TX2450	U5W
Panasonic	TX2464	U5
Panasonic	TX2470	ALPHA1W
Panasonic	TX2472	ALPHA1X
Panasonic	TX2480	ALPHA1
Panasonic	TX2482	ALPHA1
Panasonic	TX2488	ALPHA1
Panasonic	TX2492	ALPHA1W
Panasonic	TX24A1	ALPHA2
Panasonic	TX24A1C	ALPHA1
Panasonic	TX24T1	ALPHA2W
Panasonic	TX24W1	ALPHA2W
Panasonic	TX251XDP	ALPHA1
Panasonic	TX25A2	ALPHA3
Panasonic	TX25A2X	ALPHA3
Panasonic	TX25A3	EURO1
Panasonic	TX25BM1	ALPHA2

Panasonic	TX25G1	ALPHA2
Panasonic	TX25MD1	EURO2L
Panasonic	TX25MD3	EURO2M
Panasonic	TX25T2	ALPHA2
Panasonic	TX25T2K	ALPHA1
Panasonic	TX25T2P	ALPHA1
Panasonic	TX25W2	ALPHA3
Panasonic	TX25W2A	ALPHA3
Panasonic	TX25W3	EURO1
Panasonic	TX25X1	ALPHA4
Panasonic	TX25X1DP	ALPHA4
Panasonic	TX2636	U4W
Panasonic	TX2646	U4W
Panasonic	TX2656	U5W
Panasonic	TX26MD1	EURO2L
Panasonic	TX28A1	ALPHA2W
Panasonic	TX28A1C	ALPHA1
Panasonic	TX28A2	ALPHA3
Panasonic	TX28A2X	ALPHA3
Panasonic	TX28A3	EURO1
Panasonic	TX28G1	ALPHA2
Panasonic	TX28LD1	EURO2
Panasonic	TX28MD3	EURO2M
Panasonic	TX28W1	ALPHA2W
Panasonic	TX28W2	ALPHA3
Panasonic	TX28W3	EURO1
Panasonic	TX28X1	ALPHA4
Panasonic	TX28X1DP	ALPHA1
Panasonic	TX29A3	EURO1
Panasonic	TX29AD1D	ALPHA1
Panasonic	TX3	ALPHA1
Panasonic	TX3300	U4
Panasonic	TX3370GR	ALPHA1
Panasonic	TX33A1	ALPHA2W
Panasonic	TX33A1G	ALPHA2
Panasonic	TX33A2	ALPHA3
Panasonic	TX37A2	ALPHA3
Panasonic	TX37A2G	ALPHA3
Panasonic	TX5500	U5
Panasonic	TXC21	U4
Panasonic	TXC22	U5
Panasonic	TXC71	ALPHA1W
Panasonic	TXC74	ALPHA1W
Panasonic	TXC78	ALPHA1W
Panasonic	TXC84	ALPHA2
Panasonic	TXC88	ALPHA2
Panasonic	TXG10	AC-1
Panasonic	TXW28D2	EURO-3HW
Panasonic	TXW32D2	EURO-3HW
Panasonic	TYSU1	ALPHA1
Panasonic	TYSU2	ALPHA1
Panasonic	TYSU3	ALPHA1
Perdio	CT2005	Indiana 100
Perdio	P1408	Indiana 100
Perdio	P1480	Indiana 100

Perdio	P2004	Indiana 100
Perdio	P2005	Indiana 100
Perdio	P2101	Indiana 100
Perdio	P2102	Indiana 100
Phase	PH20567	Murphy CTV3500
Philips	797	K12
Philips	912	TX
Philips	928	KT3
Philips	934	KT3
Philips	1201	K30
Philips	1205	K30
Philips	1234	K30
Philips	1250	K30
Philips	2206	CTX
Philips	2216	CTX
Philips	2226	CTX
Philips	2601	K12Z
Philips	2605	K12Z
Philips	3205	KT3
Philips	3215	KT3
Philips	3245	K35
Philips	3275	K35
Philips	3715	KT3
Philips	3745	K35
Philips	3775	K35
Philips	3850	K35
Philips	3880	K35
Philips	3890	K35
Philips	3895	K35
Philips	4206	KT4
Philips	4360	K40
Philips	4418	KT4
Philips	4526	KT4
Philips	4616	KT4
Philips	4718	KT4
Philips	4728	KT4
Philips	4860	K40
Philips	4880	K40
Philips	6620	KT4
Philips	6720	K40
Philips	6820	K40
Philips	10CX1120	Pye 25KX1201
Philips	12B611	T8
Philips	12B710	TX
Philips	12B711	TX
Philips	12B912	TX
Philips	12B915	TX
Philips	12TX1501	TX1
Philips	12TX2301	TX2
Philips	12TX2460	TX2
Philips	12TX2501	TX2
Philips	12TX2502	TX2
Philips	12TX3201	TX3
Philips	12TX3301	TX3
Philips	12TX3303	TX3

Philips	12TX3501	TX3
Philips	12TX3502	TX3
Philips	14B614	T8
Philips	14C825	KT2
Philips	14C925	KT3
Philips	14CE1200	CP90
Philips	14CE1201	CP90
Philips	14CE1210	CP90
Philips	14CE1500	CP90
Philips	14CF1014	CF1
Philips	14CF1114	CF1
Philips	14CN2201	NC3-CR
Philips	14CN3001	NC3
Philips	14CT2006	CTX-S
Philips	14CT2007	CTX-E
Philips	14CT2201	CTX-E
Philips	14CT2206	CTX-E
Philips	14CT3005	KT3
Philips	14CT3205	KT3
Philips	14CT3605	KT3
Philips	14CT3606	KT3
Philips	14CT3607	KT3
Philips	14CT4206	KT4
Philips	14GR1021	GR1-AX
Philips	14GR1212	GR1-AX
Philips	14GR1220	GR1-AX
Philips	14GR1221	GR1-AX
Philips	14GR1227	GR1-AX
Philips	14GR2520	G90AE
Philips	14PT121A	GR1-AX
Philips	14PT135B	ANUBIS A
Philips	14PT155A	ANUBIS A
Philips	14PT156A	ANUBIS A
Philips	14TVCR24	COMBI
Philips	14TX1504	TX-14
Philips	14TX2504	TX2
Philips	14TX3504	TX3
Philips	14TX3540	TX3
Philips	15AA3332	ANUBIS A
Philips	15CE1010	CP90
Philips	15CE1210	CP90
Philips	15CE1510	CP90
Philips	15CE1518	CP90
Philips	15CT2309	CTX-E
Philips	15GR2330	G90AE
Philips	15GR2331	G90AE
Philips	15GR2350	G90AE
Philips	15GR2530	G90AE
Philips	16C927	KT3
Philips	16C928	KT3
Philips	16CT2016	CTX-E
Philips	16CT2216	CTX-E
Philips	16CT3015	KT3
Philips	16CT3215	KT3
Philips	16CT3715	KT3

Philips	16CT4418	KT4
Philips	16CT4616	KT4
Philips	16CT4718	KT4
Philips	17B920	E2
Philips	17B920/15X	E2
Philips	17CE1230	CP90
Philips	17CE1530	CP90
Philips	17CE1538	CP90
Philips	17CE1630	CP90
Philips	17CT2319	CTX-E
Philips	17CT2619	CTX-E
Philips	17GR2340	G90AE
Philips	17GR2341	G90AE
Philips	17GR2540	G90AE
Philips	17HT1340	ANUBIS B
Philips	17HT1540	ANUBIS B
Philips	17HT1549	ANUBIS B
Philips	17PT1563/05	L7.2E AA
Philips	20C933	KT3
Philips	20C934	KT3
Philips	20CT2026	CTX-E
Philips	20CT2035	CTX-E
Philips	20CT2036	CTX-E
Philips	20CT2235	CTX-E
Philips	20CT2236	CTX-E
Philips	20CT2635	CTX-E
Philips	20CT2636	CTX-E
Philips	20CT3027	KT3
Philips	20CT3036	KT3
Philips	20CT3227	KT3
Philips	20CT3723	KT3
Philips	20CT3726	KT3
Philips	20CT4428	KT4
Philips	20CT4626	KT4
Philips	20CT4636	KT4
Philips	20CT4728	KT4
Philips	20PT2381/73R	L7.1A.AA
Philips	21AA3350	ANUBIS A
Philips	21CE1051	CP90
Philips	21CE1059	CP90
Philips	21CE1250	CP90
Philips	21CE1251	CP90
Philips	21CE1259	CP90
Philips	21CE1550	CP90
Philips	21CE1551	CP90
Philips	21CE1557	CP90
Philips	21CE1558	CP90
Philips	21CE1559	CP90
Philips	21CE2340	2A
Philips	21CE2640	2A
Philips	21CE4450	2B
Philips	21CE4550	2B
Philips	21CE4559	2B
Philips	21CE5554	2B
Philips	21CE7550	3A

Philips	21CE7650/	3A
Philips	21CT4829	KT4
Philips	21GR1251	GR1-AX
Philips	21GR2150	G90AE
Philips	21GR2350	G90AE
Philips	21GR2550	G90AE
Philips	21GR2552	G90AE
Philips	21GR2554	G90AE
Philips	21GR2752	G90B
Philips	21GR9752	G90B
Philips	21HT1350	ANUBIS B
Philips	21HT1550	ANUBIS B
Philips	21HT1559	ANUBIS B
Philips	21PT1532	L6.1AA
Philips	21PT165B	AA5-AB
Philips	21PT166B	AA5-AB
Philips	21ST1730	GR2.1
Philips	21ST2730	GR2.1
Philips	22AV3500	CP90
Philips	22CE2060	2A
Philips	22CE2061	2A
Philips	22CE2065	2A
Philips	22CE2261	2A
Philips	22CE2267	2A
Philips	22CE2561	2A
Philips	22CE2565	2A
Philips	22CE2567	2A
Philips	22CS1002	K30
Philips	22CS1201	K30
Philips	22CS1205	K30
Philips	22CS1234	K30
Philips	22CS3040	K35
Philips	22CS3245	K35
Philips	22CS3745	K35
Philips	22CS3761	K35
Philips	22CS3850	K35
Philips	22CS3880	K35
Philips	22CS4360	K40
Philips	22CS4860	K40
Philips	22CS4861	K40
Philips	22CS5240	K40
Philips	22CS5350	K40
Philips	22CS5735	K40
Philips	22CS5740	K40
Philips	22CS5744	K40
Philips	22CS5748	K40
Philips	22CS5750	K40
Philips	22CS5751	K40
Philips	22CT2226	CTX-E
Philips	23TC2001	TC2
Philips	24CE2370	2A
Philips	24CE2670	2A
Philips	24CE3270	CP110
Philips	24CE3271	CP110
Philips	24CE3570	CP110

Philips	24CE3578	CP110
Philips	24CE3588	CP110
Philips	24CE4570	2B
Philips	24CE4579	2B
Philips	24CE7570	3A
Philips	25CE5574	2B
Philips	25CE6270	CP110
Philips	25CE6570	CP110
Philips	25GR5560	G110
Philips	25GR57	G110
Philips	25GR5762	G110
Philips	25GR5763	G110
Philips	25GR5764	G110-NIC
Philips	25GR9762	G110
Philips	25GR9763	G110
Philips	25GR9768	G110
Philips	25ML8300	FL1.7
Philips	25MN1550	GR2.1
Philips	25PT410A	GR2.1
Philips	25PT4103/05	L6.2AA
Philips	25PT4501	MD1.1E
Philips	25PT4521	MD1.1E
Philips	25PT632A/05	GR2.4AA
Philips	25ST1724	GR2.1
Philips	25ST2761	GR2.2AA
Philips	26C797	K12
Philips	26CE2080	2A
Philips	26CE2081	2A
Philips	26CE2281	2A
Philips	26CE2581	2A
Philips	26CP2601	K12
Philips	26CS1009	K30
Philips	26CS1205	K30
Philips	26CS1250	K30
Philips	26CS3070	K35
Philips	26CS3275	K35
Philips	26CS3775	K35
Philips	26CS3880	K35
Philips	26CS3890	K35
Philips	26CS3895	K35
Philips	26CS4880	K40
Philips	26CS4895	K40
Philips	26CS5770	K40
Philips	26CS5774	K40
Philips	26CS5793	K40
Philips	27CE2390	2A
Philips	27CE2690	2A
Philips	27CE3290	CP110
Philips	27CE3590	CP110
Philips	27CE3598	CP110
Philips	27CE7590	3A
Philips	27CE7593	3A
Philips	27CE7690	3A
Philips	27CE7790	3A
Philips	27CS6895	K40

Philips	28777SIR	G110 NICAM
Philips	28CE5594	2B
Philips	28CE6590	CP110
Philips	28DC2070	D16-111
Philips	28GR5772	G110
Philips	28GR9772	G110
Philips	28ML8770	FL12
Philips	28ML8800	FL1.6
Philips	28ML8916	FL12
Philips	28PW9623/05	MD2.25AA
Philips	29PT9113	MD2.2AA
Philips	31BX2013	TX2
Philips	31BX2016	TX2
Philips	31BX2125	TX2
Philips	31BX3025	TX3
Philips	31BX3033	TX3
Philips	31BX3112	TX3
Philips	31BX3115	TX3
Philips	32PW9763/25	MD2.25
Philips	33CE7533	3A
Philips	33DC2080	D16-111
Philips	35BX1045	TX14
Philips	35BX2045	TX2
Philips	37CS5600	K40
Philips	37K6225	KT2
Philips	37KT2040	CTX-E
Philips	37KV1240	GR1-AX
Philips	37KV1242	GR1-AX
Philips	37KV2225	G90AE
Philips	38KV2325	G90AE
Philips	41GR8840	G110
Philips	41GR8841	G110
Philips	42CT2142	CTX-E
Philips	43KV2425	G90AE
Philips	51BE2080	E2
Philips	51BL7205	L7
Philips	51BL7215	L7
Philips	52KE2406	2A
Philips	52KV1528	GR1-AX
Philips	52KV2523	G90AE
Philips	52KV2525	G90AE
Philips	52KV2529	G90AE
Philips	52ZY3535	ANUBIS A
Philips	56KE2600	2A
Philips	56KE2610	2A
Philips	56KS5487	K40
Philips	59KE3702	CP110
Philips	60CP2605	K12Z
Philips	61BL7245	L7
Philips	63KV9637	G110
Philips	68KE7827	3A
Philips	9TC2000	TC2
Philips	9TC2100	TC2
Philips	CE2640	2A
Philips	CP2605	K12Z

Philips	CS1234	K30
Philips	CS1250	K30
Philips	CS3890	K35
Philips	CT2006	CTX
Philips	CT2206	CTX-E
Philips	CTV105	CP90
Philips	CTV111	CP90
Philips	CTV114	CP110
Philips	CTV117	CP110
Philips	CTV121	CP90
Philips	D14GY1	NC3-CR
Philips	D14KP3	CP90
Philips	D14KP4	NC3-CR
Philips	D36EP1	CP90
Philips	D36FY5	CP90
Philips	D36GP5	CP90
Philips	D36GP6	G90AE
Philips	D41FP2	CP90
Philips	D51EP2	CP90
Philips	D51EP4	CP90
Philips	D51EP5	CP90
Philips	D51FP3	CP90
Philips	D51FP4	CP90
Philips	D51FP5	CP90
Philips	D51FP6	CP90
Philips	D51GP2	G90AE
Philips	D51GP5	G90AE
Philips	D51GY4	G90AE
Philips	D51HY2	G90AE
Philips	D51JP4	G90AE
Philips	D51KP6	CP90
Philips	D59EP2	2B
Philips	D59EP3	CP110
Philips	D59EP6	CP110
Philips	D59EPC	CP110
Philips	D59FP2	CP110
Philips	D59FP3	CP110
Philips	D59FP4	CP110
Philips	D59FP5	CP110
Philips	D59FP6	CP110
Philips	D59FY5	CP110
Philips	D59GP4	CP110
Philips	D59HY5	CP110
Philips	D59JP4	CP110
Philips	D59JP6	GR2.1
Philips	D66EP4	CP110
Philips	D66EP5	CP110
Philips	D66EP6	CP110
Philips	D66FY5	CP110
Philips	G20657	G11
Philips	G20C560	G8
Philips	G20C655	G11
Philips	G22C566	G11
Philips	G22C567	G11
Philips	G22C569	G11

Philips	G22C655	G11
Philips	G22C657	G11
Philips	G22C660	G11
Philips	G22C661	G11
Philips	G22C662	G11
Philips	G22C663	G11
Philips	G22C664	G11
Philips	G22C665	G11
Philips	G22C666	G11
Philips	G22C667	G11
Philips	G22C700	G11
Philips	G22C701	G11
Philips	G22C702	G11
Philips	G22C703	G11
Philips	G22C705	G11
Philips	G22C706	G11
Philips	G22C707	G11
Philips	G22C708	G11
Philips	G26C672	G11
Philips	G26C674	G11
Philips	GR2330	G90AE
Philips	KE3715	CP110
Philips	KT2040	CTX-E
Philips	KT2366	CTX-E
Philips	KT4146	KT4
Philips	KV2523	G90AE
Philips	STC2100	TC2
Philips	TX3303	TX3
Philips	V6600	KT3
Philips	V6620	KT4
Philips	V6621	KT4
Philips	V6651	KT4
Philips	V6720	K40
Philips	V6721	K40
Philips	V6820	K40
Philips	V6821	K40
Philips	V6851	K40
Philips	V7001	K40
Philips	VP120	KT4
Pilot	CTV735	THORN 9500
Pilot	P735	THORN 9500
Pilot	P798A	Ferguson TX9
Pilot	P8039	Ferguson TX9
Pioneer	AV28	ITT Core
Pioneer	SD21AVI	Nokia Compact D-E
Pioneer	SD25AVI	Nokia Compact D-E
Pioneer	SD28AVI	Nokia Compact D-E
Pioneer	SV2103	2A/2B?
Pioneer	SV2503	2B
Pioneer	SV2803	2B
Proline	1415T	Ferguson TX807
Proline	360TT	Decca 170
Proline	NV2400	Decca 180
Proline	NV2700	Decca 180
Protec	3731	11AK20

Protec	3743	11AK08-12
Protec	5078	11AK20
Protec	5166	11AK19
Protec	7295	11AK12
Pye	1022	K30
Pye	1042	K30
Pye	1062	K30
Pye	1826	K12
Pye	2013	TX2
Pye	2056	K12Z
Pye	2060	CTX
Pye	2062	CTX
Pye	2162	CTX
Pye	2260	CTX
Pye	3030	NC3
Pye	3052	KT3
Pye	3062	KT3
Pye	3152	KT3
Pye	3157	KT3
Pye	3237	KT3
Pye	3267	KT3
Pye	3457	K30
Pye	3508	K35
Pye	3757	K30
Pye	3808	K35
Pye	3908	K35
Pye	4146	KT4
Pye	4184	KT4
Pye	4187	KT4
Pye	4266	KT4
Pye	4284	KT4
Pye	4287	KT4
Pye	4309	KT4
Pye	4508	K40
Pye	4509	K40
Pye	4808	K40
Pye	25KX1201	Philips 10CX1120
Pye	27KE1112	CP90
Pye	27KE1115	CP90
Pye	31BX2013	TX2
Pye	31BX2016	TX2
Pye	31BX2125	TX3
Pye	31BX3025	TX3
Pye	31BX3033	TX3
Pye	31BX3046	TX3
Pye	31BX3112	TX3
Pye	31BX3115	TX3
Pye	35BX1045	TX-14"
Pye	35BX2045	TX2
Pye	35BX3045	TX3
Pye	37K7225	KT3
Pye	37KE1022	CP90
Pye	37KE1025	CP90
Pye	37KF1140	CF1
Pye	37KN2010	NC3CR

Pye	37KN2012	NC3CR
Pye	37KN3030	NC3
Pye	37KT2040	CTX-E
Pye	37KT2042	CTX-E
Pye	37KT2060	KT3
Pye	37KT2062	KT3
Pye	37KT3052	KT3
Pye	37KT3062	KT3
Pye	37KT7225	KT3
Pye	37KV1232	GR1-AX
Pye	37KV1240	GR1-AX
Pye	37KV1242	GR1-AX
Pye	37KV2225	G90AE
Pye	38KE1102	CP90
Pye	38KE1185	CP90
Pye	38KT2093	CTX-E
Pye	38KV2325	G90AE
Pye	41KT3152	KT3
Pye	42K7227	KT3
Pye	42K7228	KT3
Pye	42KT2140	CTX-E
Pye	42KT2142	CTX-E
Pye	42KT2160	CTX-E
Pye	42KT2162	CTX-E
Pye	42KT3150	KT3
Pye	42KT3152	KT3
Pye	42KT3157	KT3
Pye	42KT4146	KT4
Pye	42KT4166	KT4
Pye	42KT4184	KT4
Pye	42KT4187	KT4
Pye	42KT5184	KT4
Pye	42KT7227	KT3
Pye	42KT7228	KT3
Pye	43KE1312	CP90
Pye	43KE1315	CP90
Pye	43KE1385	CP90
Pye	43KE2196	CTX-E
Pye	43KE2425	G90AE
Pye	43KT2198	CTX-E
Pye	43KV2429	G90-AE
Pye	44T7220	E2
Pye	51BE2080	E2
Pye	51BL7205	L7
Pye	51BL7215	L7
Pye	51K7324	KT3
Pye	51K7326	KT3
Pye	51KT2260	CTX-E
Pye	51KT2262	CTX-E
Pye	51KT2360	CTX-E
Pye	51KT2362	CTX-E
Pye	51KT2366	CTX-E
Pye	51KT3237	KT3
Pye	51KT3260	KT3
Pye	51KT3262	KT3

Pye	51KT3267	KT3
Pye	51KT3272	KT3
Pye	51KT4226	KT4
Pye	51KT4284	KT4
Pye	51KT4287	KT4
Pye	51KT4309	KT4
Pye	51KT4366	KT4
Pye	51KT5287	KT4
Pye	51KT7323	KT3
Pye	51KT7324	KT3/4
Pye	51KT7326	KT3
Pye	52KE1510	CP90
Pye	52KE1512	CP90
Pye	52KE1515	CP90
Pye	52KE1585	CP90
Pye	52KE2403	2A
Pye	52KE2406	2A
Pye	52KE4505	2B
Pye	52KV1528	GR1-AX
Pye	52KV2523	G90AE
Pye	52KV2525	G90AE
Pye	52KV2529	G90AE
Pye	56KE2600	2A
Pye	56KE2610	2A
Pye	56KE2612	2A
Pye	56KE2615	2A
Pye	56KS1042	K30
Pye	56KS1060	K30
Pye	56KS1062	K30
Pye	56KS1070	K30
Pye	56KS3400	K35
Pye	56KS3452	K35
Pye	56KS3457	K35
Pye	56KS3477	K35
Pye	56KS3500	K35
Pye	56KS3508	K35
Pye	56KS4508	K40
Pye	56KS4509	K40
Pye	56KS5402	K40
Pye	56KS5418	K40
Pye	56KS5447	K40
Pye	56KS5457	K40
Pye	56KS5487	K40
Pye	56KS5503	K40
Pye	56KS5507	K40
Pye	56KS5513	K40
Pye	56KS5553	K40
Pye	56KS5557	K40
Pye	56KS5563	K40
Pye	56KS5567	K40
Pye	56KS5577	K40
Pye	59KE2703	2A
Pye	59KE2706	2A
Pye	59KE3702	CP110
Pye	59KE3715	CP110

Pye	59KE3775	CP110
Pye	59KE3785	CP110
Pye	59KE4705	2B
Pye	59KE4795	2B
Pye	61BL7245	L7
Pye	63KE5765	2B
Pye	63KE6722	CP110
Pye	63KE6725	CP110
Pye	66KE2800	2A
Pye	66KE2812	2A
Pye	66KE2815	2A
Pye	66KS1020	K30
Pye	66KS1022	K30
Pye	66KS1152	K30
Pye	66KS3700	K35
Pye	66KS3752	K35
Pye	66KS3757	K35
Pye	66KS3808	K35
Pye	66KS3908	K35
Pye	66KS4808	K40
Pye	66KS5702	K40
Pye	66KS5787	K40
Pye	66KS5917	K40
Pye	68KE2903	2A
Pye	68KE2906	2A
Pye	68KE3902	CP110
Pye	68KE3915	CP110
Pye	68KE7807	3A
Pye	68KE7827	3A
Pye	70KE6925	CP110
Pye	86KE3985	CP110
Pye	C823	725
Pye	CT420	G11
Pye	CT450	G11
Pye	CT451	G11
Pye	CT452	G11
Pye	CT453	G11
Pye	CT454	G11
Pye	CT455	G11
Pye	CT456	G11
Pye	CT457	G11
Pye	CT462	G11
Pye	CT464	G11
Pye	CT467	G11
Pye	CT474	G11
Pye	CT480	G11
Pye	CT481	G11
Pye	CT483	G11
Pye	CT484	G11
Pye	CT492	G11
Pye	CT493	G11
Pye	CT494	G11
Pye	T183	E2
Pye	T190	TX
Pye	T191	TX

Pye	T192	TX
Pye	T193	TX
Pye	T194	TX
Pye	T195	TX
Pye	T196	TX
Rediffusion	365018	Mk5
Rediffusion	365118	Mk5
Rediffusion	365130	Mk5
Rediffusion	564058	Mk4
Rediffusion	674051	Mk4
Rediffusion	674058	Mk4
Rediffusion	674358	Mk4
Saba	SB9221	Ferguson ICC7
Saisho	CM145R	
Saisho	CM159TX	Bush 2020
Saisho	CM16R	
Saisho	CM16TT	
Saisho	CM2080	
Saisho	CM20TT	
Saisho	CM250R	
Saisho	CM260TT	Fidelity ZX5000
Saisho	CM2880TX	Matsui 2890
Saisho	CT1400	Amstrad CTV1401
Saisho	CT141	Matsui 1420
Saisho	CT141X	Matsui 1420A
Saisho	CT142R	Matsui 1440
Saisho	CT142RX	Matsui 1440A
Saisho	CT147R	Matsui 1450
Saisho	CT147R	Boots CTV1414R
Saisho	CT149	Matsui 1480
Saisho	CT149TX	Matsui 2080
Saisho	CT149X	Matsui 1480A
Saisho	CT14R	Amstrad CTV1409
Saisho	CT14R	Triumph CTV820
Saisho	CT162R	Matsui 1640
Saisho	CT1800	Matsui 1810
Saisho	CT204	Logik 690
Saisho	CT208	Logik 698
Saisho	CT208TT	
Saisho	CT20S	Panasonic U4/W
Saisho	CT22S	Panasonic U4/W
Saisho	CX14R	Orion CTV144
Saisho	CX16R	Triumph CTV8312
Saisho	FST210R	Matsui 2160
Saisho	FST212T	Matsui 2180TT
Saisho	FST2130TX	Matsui 2190
Saisho	FST2530TX	Matsui 2590
Salora	16R19	ITT PICO S2
Salora	21C5	ITT CORE 2 90DEG
Salora	21C60	ITT CORE 2 90DEG
Salora	21D61	ITT CORE 2 90DEG
Salora	21M8	M80
Salora	21N60	ITT EUROSTEREO 1
Salora	21S5U	ITT EUROMONO 1 & 2
Salora	22J40	Hitachi CPT2050

Salora	25C51	ITT CORE 2 110DEG
Salora	25C60	ITT CORE 2 110DEG
Salora	25C61	ITT CORE 2 110DEG
Salora	25M87	M80
Salora	25M9C	M2 DIGI STEREO
Salora	25N6U	ITT EUROSTEREO 1
Salora	25S5U	ITT EUROMONO 1 & 2
Salora	28F8	ITT EURODIGI 16:9
Salora	28M87	M80
Salora	28M9C	M90
Salora	32F8	ITT EURODIGI 16:9
Salora	32F9C	ITT EURODIGI 16:9
Salora	33E7S	E
Salora	33M9C	ITT M2 DIGI STEREO
Salora	36F8	ITT EURODIGI 16:9
Samsung	BT110	Alba PTC9C
Samsung	BT309K	UWA 12/14" Mono
Samsung	BT510	Goodmans Q9001
Samsung	CI-125	Goodmans GTV9200
Samsung	CI-210R	Nikai Baby 10
Samsung	CI-212	
Samsung	CI-213	10" portable
Samsung	CI-330	
Samsung	CI-3312	Portable P58SC
Samsung	CI-3351	Thorn C15012R
Samsung	CI3352	P68
Samsung	CI-3352	P68
Samsung	CI-338	P50
Samsung	CI338G	P50F
Samsung	CI338Z	P36A
Samsung	CI340	P50
Samsung	CI-340	P50
Samsung	CI340ZA	P50
Samsung	CI347	P50F
Samsung	CI-347	P50
Samsung	CI347F	P50F
Samsung	CI347FF	P50F
Samsung	CI-348	P50
Samsung	CI-3482	
Samsung	CI-5012	P58SC
Samsung	CI-5013	P58SC
Samsung	CI5013T	P58SC
Samsung	CI-5030	
Samsung	CI-5052	P68SW
Samsung	CI5052AT	P68
Samsung	CI5052X	P68
Samsung	CI-5061	
Samsung	CI5103	P58SC
Samsung	CI5103T	P58SC
Samsung	CI514	P36A
Samsung	CI-514	P50
Samsung	CI514Z	P36A
Samsung	CI-517	P50
Samsung	CI5312	U88MT
Samsung	CI5322	P68T

Samsung	CI5322XT	P68T
Samsung	CI-5337	US60A
Samsung	CI537	P55
Samsung	CI-537	P55
Samsung	CI5373	SCT11D
Samsung	CI537V	P55
Samsung	CI541	P58SH
Samsung	CI-541	P55/P58?
Samsung	CI541ZG	P58SH
Samsung	CI-591	
Samsung	CI5913	U88MT
Samsung	CI5935	P70
Samsung	CI5935T	P70
Samsung	CI5935Z	P70
Samsung	CI5937	Z68
Samsung	CI-6229	P72
Samsung	CI6229T	P72
Samsung	CI-6230	P72
Samsung	CI6813	U88MT
Samsung	CI6835	P70
Samsung	CI6835T	P70
Samsung	CI6835Z	P70
Samsung	CI6837AN	Z68
Samsung	CI7230	U88MT
Samsung	CS6818	Z66/RM11
Samsung	CW5012	P54
Samsung	SV421	DX5-R
Samsung	SV821	DX5-R
Samsung	TO-6ZX	Z66/RM11
Samsung	TVP3350	SCV11A
Samsung	Voyager 10	
Samsung	VT306K	Tashiko 12D971
Sanyo	12T232	12" Mono
Sanyo	14M1	EC2-A14
Sanyo	14MT1	EC3-A
Sanyo	21M1	EC3-A21
Sanyo	21MT1	EC3-A21
Sanyo	CB1443	EC23
Sanyo	CB1456	EC3-A
Sanyo	CB5146	EC1-B21
Sanyo	CB5149	EB2
Sanyo	CB5153	EC3-A21
Sanyo	CB5156	EC3-A21
Sanyo	CB5159	EB2-A
Sanyo	CB5953	E3-A25
Sanyo	CB5956	EC3-A25
Sanyo	CB5959	EB2-A
Sanyo	CB6657	EB2-A
Sanyo	CBP2145	E2-B21
Sanyo	CBP2146	E2-E21
Sanyo	CBP2147	E2-G21
Sanyo	CBP2148	E2-G21
Sanyo	CBP2151	E4-A21
Sanyo	CBP2152	E4-A21
Sanyo	CBP2162	E4

Sanyo	CBP2168	EC1
Sanyo	CBP2180	A5-A21
Sanyo	CBP2180A	A5-A21
Sanyo	CBP2551	E4-A25
Sanyo	CBP2552	E4-A25
Sanyo	CBP2560	
Sanyo	CBP2565	E3-A25
Sanyo	CBP2566	E3-A25
Sanyo	CBP2572	ED1-25
Sanyo	CBP2573	ED1-25
Sanyo	CBP2576	ED0
Sanyo	CBP2580	EB1-25
Sanyo	CBP2865	E3-A28
Sanyo	CBP2866	E3-A28
Sanyo	CBP2872	ED1-28
Sanyo	CBP2873	ED1-28
Sanyo	CBP2876	EB1A
Sanyo	CBP3000	80P-G14
Sanyo	CBP3001	A1-A14
Sanyo	CBP3011	A1-A14
Sanyo	CBP3012	A3-A14/A28
Sanyo	CBP3018	
Sanyo	CBP3024	A3-A14
Sanyo	CBP5156	
Sanyo	CBP7110	80P-D22
Sanyo	CBT2558	E3
Sanyo	CBT2576	ED0
Sanyo	CBT2876	ED0
Sanyo	CBT2846	E2
Sanyo	CEP7100	
Sanyo	CMX2100	83S-C21
Sanyo	CPB2552	E4-A25
Sanyo	CPB2558	E3
Sanyo	CPT3104	
Sanyo	CTP2180	
Sanyo	CTP3101	
Sanyo	CTP3104	78P88Z800
Sanyo	CTP3105	79P
Sanyo	CTP3106	80P-B14
Sanyo	CTP3131	80P-B14
Sanyo	CTP3132	80P-B14
Sanyo	CTP3134	83P-D14
Sanyo	CTP3141	83P-C14
Sanyo	CTP3144	E2-A14
Sanyo	CTP3246	80P
Sanyo	CTP370	
Sanyo	CTP4100	79P
Sanyo	CTP4132	80P-G16
Sanyo	CTP4144	E2-A16
Sanyo	CTP5103	
Sanyo	CTP6102	
Sanyo	CTP6112	
Sanyo	CTP6113	
Sanyo	CTP6114	
Sanyo	CTP6124	80P-A20

Sanyo	CTP6130	80P-D20
Sanyo	CTP6131	80P-D20
Sanyo	CTP6132	80P-D20
Sanyo	CTP6133	80P-D20
Sanyo	CTP6134	83P-D20
Sanyo	CTP6135	83P-D20
Sanyo	CTP6143	
Sanyo	CTP6144	E2-B20
Sanyo	CTP6229	80P
Sanyo	CTP7118	
Sanyo	CTP7130	80P
Sanyo	CTP7131	80P-F22
Sanyo	CTP7132	80P-F22
Sanyo	CTP7133	80P-F22
Sanyo	CTP7135	80P-F22
Saville	XMP25	Goldstar P58A
SEG	CT1900	11AK08-9A
Sentra	GX9200	Nikkai TLG0101
Sentra	STX600	Nikkai NT20
Sharp	37AM12	5BS
Sharp	37AM23	5BSA
Sharp	37AT25	5BSA
Sharp	37VT24	VP-5
Sharp	51AT15	5BSA
Sharp	51CS03	CS
Sharp	51CS05	CS
Sharp	59CS03	CS
Sharp	59CS05	CS
Sharp	66AS05	4BSC
Sharp	66AS06	BCTV-A
Sharp	66CS03	CS
Sharp	66CS05	CS
Sharp	66DS03H	CA10
Sharp	C095	
Sharp	C1001	
Sharp	C1410	4PS
Sharp	C1411	4PSR1
Sharp	C1412	
Sharp	C1420	7PS
Sharp	C1420H	7PS
Sharp	C1421	7PSR1
Sharp	C1430	8PS
Sharp	C1431	8PSR
Sharp	C1431H	8PSR
Sharp	C1480	TAP-812
Sharp	C1491	Rediffusion Mk5
Sharp	C1493	
Sharp	C1495	
Sharp	C1871	
Sharp	C1891	
Sharp	C2002	
Sharp	C2072	
Sharp	C2092	
Sharp	C2095	
Sharp	C3703	7PS

Sharp	C3703H	7PS
Sharp	C3703HBK	7PS
Sharp	C3704	8PS
Sharp	C3705	4PSR1
Sharp	C3705H	4PS
Sharp	C3706	14B
Sharp	C3706H	14B
Sharp	C3709	7PS
Sharp	C3710	8PSR
Sharp	C3710H	8PSR
Sharp	C3720	14A
Sharp	C3720H	14A
Sharp	C3730	14B
Sharp	C3730H	14B
Sharp	CV2121	7PSR1
Sharp	CV2121H	7PSR1
Sharp	CV2123	7PSR1
Sharp	CV2123H	7PSR1
Sharp	CV2131	8PSR
Sharp	CV2133	8PSR
Sharp	CV2133H	8PSR
Sharp	CV3707	5P-SR1
Sharp	CV3707H	5PS
Sharp	CV3709H	7PS
Sharp	CV3730	
Sharp	CV3745	14B
Sharp	CV4833	14B
Sharp	CV5407	5PS
Sharp	DV1512	Euro DS1
Sharp	DV1600	
Sharp	DV1620	
Sharp	DV2120	4PS
Sharp	DV2121	4PS
Sharp	DV3750	S3B
Sharp	DV3750H	S3B
Sharp	DV3751	S3B
Sharp	DV3751H	S3B
Sharp	DV3760	4BSA
Sharp	DV3760H	4BSA
Sharp	DV3761	4BSC
Sharp	DV3761H	4BSC
Sharp	DV3770	4BSA
Sharp	DV3770H	4BSA
Sharp	DV4205	4PS
Sharp	DV5101	EURO-DS
Sharp	DV5101H	EURO-DS
Sharp	DV5103	EURO-DS
Sharp	DV5103H	EURO-DS
Sharp	DV5105	DECO-4
Sharp	DV5105H	DECO-4
Sharp	DV5107	DECO-5
Sharp	DV51083	D3000
Sharp	DV51083H	D3000
Sharp	DV5131	S3B
Sharp	DV5131H	S3B

Sharp	DV5132	DECO-5
Sharp	DV5132H	DECO-5
Sharp	DV5135	DECO-5
Sharp	DV5135H	DECO-5
Sharp	DV5150	S3B
Sharp	DV5150H	S3B
Sharp	DV5161	4BSA
Sharp	DV5161H	4BSA
Sharp	DV5165	4BSB
Sharp	DV5180	4BSB
Sharp	DV5404	German model
Sharp	DV5903	D3000
Sharp	DV5903H	D3000
Sharp	DV59083	D3000
Sharp	DV5932	BCTV-A
Sharp	DV5932H	BCTV-A
Sharp	DV5935	BCTV-A
Sharp	DV5935H	BCTV-A
Sharp	DV5937	
Sharp	DV5940H	4BSC
Sharp	DV6603	D3000
Sharp	DV6603H	D3000
Sharp	DV66083	D3000
Sharp	DV66083H	D3000
Sharp	DV6632	4BSC
Sharp	DV6632H	4BSC
Sharp	DV6635	BCTV-A
Sharp	DV6635H	BCTV-A
Sharp	SV2189	8PLS
Sharp	SV257	NC-7
Sharp	SV2588	8PLS
Sharp	SV2588H	8PLS
Sharp	SV2589	8PLS
Sharp	SV2589H	8PLS
Sharp	SV287	NC-7
Sharp	SV2888	8PLS
Sharp	SV2888H7	8PLS
Sharp	SV2889	8PLS
Sharp	SV3320	8PLP1
Sharp	VT3700	VP1
Sharp	VT3705	VP1
Skantic	3781	180
Skantic	5111	BC
Skantic	5114	BC
Skantic	5601	BC
Skantic	5608	BC
Skantic	6711	BC
Skantic	6718	BC
Skantic	18051919	B2
Solarvox	142TT	
Solarvox	14R19	CVC1110/12
Solarvox	14S09	CVC1110/12
Solarvox	14S19	ITT PICO S/2
Solarvox	16R19	ITT PICO S/2
Solarvox	20R09	ITT MINI 2 ST2/2

Solarvox	20S09	ITT CVC1175
Solarvox	20S19	ITT PICO S/2
Solarvox	20T09	ITT CVC1200/1
Solarvox	20T19	ITT MINI2
Solarvox	22R09	ITT CVC1215
Solarvox	22S09	ITT CVC1200/1
Solarvox	22S19	ITT COMPACT 80/R
Solarvox	22T09	ITT CVC1215
Solarvox	22T09TX	ITT CVC1210
Solarvox	26R09	ITT CVC1212/17
Solarvox	26SR09	ITT CVC1212/17
Solarvox	26ST09	ITT CVC1212/17
Solarvox	26T09	ITT CVC1212/17
Solarvox	CML14	Hinari CT4 / 5
Solarvox	CML14RC	Nikkai TLG0101
Sony	CKV2760	
Sony	FDL390	
Sony	KP41DS1U	RE2
Sony	K14M1U	BE4
Sony	KP41S3U	RE1
Sony	KP41S4U	RE2
Sony	KPS4112	AP1E
Sony	KT-X1420UB	SCC-603-A
Sony	KV-1201UB	SCC23A-A
Sony	KV1300	
Sony	KV1310	
Sony	KV1320	
Sony	KV1330	
Sony	KV1340	
Sony	KV-1352E	P-2E
Sony	KV1400	
Sony	KV1412	XE3
Sony	KV1412UB	XE3
Sony	KV1430	XE3
Sony	KV-1430UB	XE-3
Sony	KV1440	XE5
Sony	KV1442	XE5
Sony	KV-1460	GP1
Sony	KV14LM1U	FE2
Sony	KV14LT1U	FE2
Sony	KV1462	GP-I
Sony	KV14M1U	BE4
Sony	KV14T1U	BE4
Sony	KV14V4U	TE1
Sony	KV14V5U	BC4
Sony	KV14V6U	BC4
Sony	KV1612	XE3
Sony	KV1612UB	SCC-251A
Sony	KV-1621	
Sony	KV16WS1U	BE5
Sony	KV16WT1U	BE4
Sony	KV16XM	GP2
Sony	KV1800	
Sony	KV1810	
Sony	KV-1820	SCC-132B-B

Sony	KV-1822UB	SCC-146C-B
Sony	KV1882	XE3
Sony	KV1882UB	XE3
Sony	KV19XM	GP2
Sony	KV19XMU	GP2
Sony	KV20WS1U	BE5
Sony	KV2000	
Sony	KV-2000UB-II/1820	SCC-132A-A & B
Sony	KV2020	
Sony	KV-2020UB	
Sony	KV2022	
Sony	KV2029	
Sony	KV2040	
Sony	KV2052	PE2
Sony	KV2052U	PE2
Sony	KV2056	PE2
Sony	KV2060	XE3
Sony	KV-2060EI	XE-3
Sony	KV2062	XE3
Sony	KV2066	XE3
Sony	KV-2075	
Sony	KV-2090	XE-4
Sony	KV-2092	XE-4
Sony	KV-2096UB	XE-4
Sony	KV-211XMTU	AE-1
Sony	KV2121U	AE-1
Sony	KV21LM1U	FE2
Sony	KV21LT1U	FE2
Sony	KV-2153MT	
Sony	KV21M1U	BE4A
Sony	KV21M3U	BE4A
Sony	KV21T1U	BE4A
Sony	KV21T3U	BE4A
Sony	KV21V4U	TE1
Sony	KV21V5U	BC4
Sony	KV21V6U	BC4
Sony	KV21X1U	BE5
Sony	KV21X4U	BE6
Sony	KV21X5U	FE1
Sony	KV-21XMTU	AE-1
Sony	KV21XMU	AE1
Sony	KV21XR	SX
Sony	KV21XRTU	SX
Sony	KV-21XRTU	SCC-778B-A SX
Sony	KV21XRU	SX
Sony	KV-21XRU	SCC-778A-A SX
Sony	KV2200	
Sony	KV-2201	YE-2
Sony	KV2202	
Sony	KV2204	SCC-244A
Sony	KV-2204UB	SCC-244A-A
Sony	KV2206	
Sony	KV2207	
Sony	KV-2212UB	YE-2
Sony	KV2215	YE2

Sony	KV-2215UB	YE2
Sony	KV2216	YE2
Sony	KV-2217UB	YE-2
Sony	KV-2252UB	PE-3/RX
Sony	KV2256	PE3
Sony	KV2256UB	PE3
Sony	KV24WS1	BE3B
Sony	KV24WSU	BE3D
Sony	KV24WS2U	BE3D
Sony	KV24WX1U	BE3D
Sony	KV-2511	AE1
Sony	KV-2521U	AE-1
Sony	KV-2562	AE2
Sony	KV25F1	BE3D
Sony	KV25F1U	BE3D
Sony	KV25F2U	BE3D
Sony	KV25K5U	FE1
Sony	KV25T1	BE3B
Sony	KV25T1U	BE3B
Sony	KV25X1	BE3D
Sony	KV25X5U	BE3D/FE1
Sony	KV2704	
Sony	KV2705	QE1
Sony	KV2706	QE1
Sony	KV-2715UB	YE-2
Sony	KV2752	PE3
Sony	KV2752UB	RX
Sony	KV-2756	PE-3
Sony	KV2762	PE3
Sony	KV-2764EC	PE-3 RM-635
Sony	KV2766	PE3
Sony	KV-27RXTU	
Sony	KV27VX	VX
Sony	KV27XR	SX
Sony	KV27XRTU	SX
Sony	KV28DS20U	BE3E
Sony	KV28DS60U	GE1A
Sony	KV28DX20U	BE3E
Sony	KV28FC60Z	AE5
Sony	KV28FD1E	GE1
Sony	KV28FQ75U	AE5
Sony	KV28FX20U	BE3E
Sony	KV28FX60U	AE5
Sony	KV28WF1U	BE3D
Sony	KV28WS1	BE3B
Sony	KV28WS2U	BE3D
Sony	KV28WS3	AE3
Sony	KV28WS3U	AE3
Sony	KV28WX1U	BE3D
Sony	KV29FS70U	AE5
Sony	KV-2922U	AE-1 C and SCC-E23B-A
Sony	KV-2962U	AE-2
Sony	KV-2972U	AE-2B
Sony	KV29F1	BE3D
Sony	KV29FX11U	BE3D

Sony	KV29F1U	BE3D
Sony	KV29F2U	BE3D
Sony	KV29F3U	BE3D
Sony	KV29FX20U	FE1
Sony	KV29K5U	FE1
Sony	KV29X1U	BE3D
Sony	KV29X5U	FE1
Sony	KV32DS20U	BE3E
Sony	KV32DS60U	GE1A
Sony	KV32DX20U	BE3E
Sony	KV32FX20U	BE3E
Sony	KV32FD1E	GE1
Sony	KV32FX60U	AE5
Sony	KV32WF1U	BE3D
Sony	KV32WS3	AE3
Sony	KV32WX2	AE4
Sony	KV36FS70U	AE5
Sony	KV-6000	
Sony	KV9000	
Sony	KVA2111	AE-1C
Sony	KVA2112	AE1C
Sony	KVA2123	AE1-C
Sony	KVA213	AE2A
Sony	KVA2131	AE2A
Sony	KVA2131A	AE2A
Sony	KVA2131B	AE2A
Sony	KVA2131D	AE2A
Sony	KVA2132	AE2A
Sony	KVA2132U	AE2A
Sony	KVA2133	AE2A
Sony	KVA2133E	AE2A
Sony	KVA2511	AE1-C
Sony	KVA2512	AE1C
Sony	KVA2513	AE1-C
Sony	KVA2522	AE1C
Sony	KVA2523	AE-1C
Sony	KVA253	AE2A
Sony	KVA2532	AE2A
Sony	KVA2533	AE-2A
Sony	KVA254	AE2B
Sony	KVA2542	AE2B
Sony	KV-A2542U	AE-2B
Sony	KVA2912	AE1C
Sony	KVA2913	AE1C
Sony	KVA2922	AE1C
Sony	KVA2923	AE-1C
Sony	KVA293	AE2A
Sony	KVA2932	AE2A
Sony	KVA2933	AE-2A
Sony	KVA294	AE2B
Sony	KVA2942	AE2B
Sony	KVA2942U	AE2B
Sony	KVA3412	DE2
Sony	KVA3412U	DE
Sony	KVA3413	DE-2

Sony	KVB2512	AE2
Sony	KVB2512U	AE2
Sony	KVB2513	AE-2
Sony	KVB2515	AE2
Sony	KVB252	AE2B
Sony	KVB2912	AE2
Sony	KVB2912U	AE2
Sony	KVB2913	AE-2
Sony	KVB2915	AE2
Sony	KVB292	AE2B
Sony	KVC2121	AE-1C
Sony	KVC2122	AE1C
Sony	KVC2123	AE-1C
Sony	KVC2163	AE-1C
Sony	KVC25	AE-1
Sony	KVC2521	AE-1B
Sony	KVC2522	AE1C
Sony	KVC2523	AE-1B
Sony	KVC2531	AE-1B
Sony	KVC2533	AE-1B
Sony	KVC2561	AE-1C
Sony	KVC2563	AE-1C
Sony	KVC2573	AE-1C
Sony	KVC27	AE-1
Sony	KVC2721	AE-1
Sony	KVC2911	AE-1
Sony	KVC2921	AE-1B
Sony	KVC2923	AE-1B
Sony	KVC2931	AE-1B
Sony	KVC2933	AE-1B
Sony	KVC2951	AE-1C
Sony	KVC2953	AE-1C
Sony	KVC2963	AE-1C
Sony	KVC2973	AE-1C
Sony	KVD2511	AE-1A
Sony	KVD2512	AE1A
Sony	KV-D2512	AE-1
Sony	KVD2512U	AE1
Sony	KVD2911	AE-1A
Sony	KVD2912	AE1A
Sony	KVD2912U	AEU
Sony	KVD2921	AE-1A
Sony	KVD3411	DE-1
Sony	KVD3412	DE1
Sony	KVD3431	DE-2
Sony	KVD3432	DE-2
Sony	KVD3433	DE-2
Sony	KVDX21	AE1
Sony	KVDX2112	AE1
Sony	KV-DX21TU	AE-1
Sony	KVDX27	AE-1
Sony	KVDX271	AE1
Sony	KVDX27T	AE1
Sony	KVE2511	AE-1A
Sony	KV-E2512	AE-1A

Sony	KVE2512U	AE1A
Sony	KVE2521	AE-1C
Sony	KVE2522	AE1C
Sony	KVE2523	AE-1C
Sony	KVE2532	AE2
Sony	KVE254	AE2A
Sony	KVE2542	AE2A
Sony	KVE2543	AE-2A
Sony	KVE255	AE2B
Sony	KVE2911	AE-1A
Sony	KVE2912	AE1A
Sony	KVE2912U	AE1A
Sony	KVE2921	AE-1C
Sony	KVE2922	AE-1C
Sony	KVE2922U	AE1C
Sony	KVE2923	AE-1C
Sony	KVE2925	AE1C
Sony	KVE2932	AE2
Sony	KVE2933	AE-2A
Sony	KVE294	AE2A
Sony	KVE2942	AE2A
Sony	KVE2942U	AE2A
Sony	KVE2943	AE-2A
Sony	KVE295	AE2B
Sony	KVE296	AE2F
Sony	KVE2963	AE-2A
Sony	KVE3433	AE-2
Sony	KVFX29	FX
Sony	KVFX2921	CE-1
Sony	KVFX2923	CE-1
Sony	KVG2515	AE2B
Sony	KV-G2515U	AE-2B
Sony	KVG2915	AE2B
Sony	KVG2915U	AE2B
Sony	KVH1510	BE-1
Sony	KVH1513	BE-1
Sony	KVH2513	AE-1C
Sony	KVM1100	EE1A
Sony	KVM1120	EE1A
Sony	KVM1400	BE2A
Sony	KVM1400U	BE2A
Sony	KVM1401	BE2A
Sony	KVM1401U	BE2A
Sony	KVM1410	BE2A
Sony	KVM1410U	BEU
Sony	KVM1411	BE2A
Sony	KVM1411U	BEU
Sony	KVM1420	BE2A
Sony	KVM1420U	BE-2A
Sony	KVM1421	BE2A
Sony	KVM1421U	BE-2A
Sony	KVM1430	BE-2A
Sony	KVM1431	BE-2A
Sony	KVM1440U	BE4
Sony	KVM1441U	BE4

Sony	KVM14TU	BE-1
Sony	KVM14U	BE1
Sony	KVM1620	BE2A
Sony	KVM1620U	BE-2A
Sony	KVM1621	BE2A
Sony	KVM1621U	BE-2A
Sony	KVM16TU	BE1
Sony	KVM16U	BE1
Sony	KVM1920	BE2A
Sony	KVM1921	BE2A
Sony	KVM1921U	BE2A
Sony	KV-M19TU	BE-1
Sony	KVM2101	BE2A
Sony	KV-M2120U	BE-1
Sony	KVM2121	BE1
Sony	KVM2121U	BE1
Sony	KVM2120	BE1
Sony	KVM2130	BE1
Sony	KVM2131	BE1
Sony	KVM2140	BE2A
Sony	KVM2140U	BE-2A
Sony	KVM2141	BE2A
Sony	KVM2141U	BE-2A
Sony	KVM2150	BE2A
Sony	KVM2150U	BE2A
Sony	KV-M2151	BE-2A
Sony	KVM2151U	BEU
Sony	KVM2170U	BE4A
Sony	KVM2171U	BE4A
Sony	KVM21TU	AE1
Sony	KVM21U	AE1
Sony	KVM21XMU	AE-1
Sony	KVM2511	AE1
Sony	KVM2521	AE1C
Sony	KVM2531	AE1C
Sony	KVM2541	BE3B
Sony	KVM531	
Sony	KVP14U	BE1
Sony	KVS2911	AE1
Sony	KVS2912	AE2
Sony	KVS2922	AE2A
Sony	KVS294	AE2F
Sony	KVS2942	AE2F
Sony	KVS2943	AE-2A
Sony	KVS2952	AE3
Sony	KVS3411	AE2
Sony	KVS3411A	AE2
Sony	KVS3411B	AE2
Sony	KVS3411D	AE2
Sony	KVS3411K	AE2
Sony	KVS3412	AE2
Sony	KVS3412U	AE2
Sony	KVS3413	AE2
Sony	KVS3413E	AE2
Sony	KVS3432	AE2B

Sony	KVV1410	BC2
Sony	KVV1430	TE1
Sony	KVW281	AE2F
Sony	KVW2812	AE2F
Sony	KVX21	AE-1
Sony	KVX2102	BE3B
Sony	KVX2102U	BE3B
Sony	KVX2121	AE1
Sony	KVX2121U	AE1
Sony	KVX2129	AE1
Sony	KVX2131	AE1B
Sony	KVX2132	AE1B
Sony	KVX2132U	AE1
Sony	KVX2133	AE1B
Sony	KVX2142	AE1C
Sony	KVX2142U	AE
Sony	KVX2152	AE1C
Sony	KVX2153	AE-1C
Sony	KVX2162	AE2
Sony	KV-X2162U	AE-2
Sony	KVX2163	AE-1C
Sony	KVX217	AE2B
Sony	KVX2172	AE2B
Sony	KVX2173	AE2B
Sony	KVX2182	BE3B
Sony	KVX2182U	BE3B
Sony	KVX21TU	AE1
Sony	KVX24WS1	BE3B
Sony	KVX25	AE1
Sony	KVX2502	BE3B
Sony	KVX2503	BE3B
Sony	KVX2521	AE1C
Sony	KVX2521U	AE1
Sony	KVX2529	AE1
Sony	KVX2529U	AE-1
Sony	KVX2531	AE1B
Sony	KVX2532	AE1B
Sony	KV-X2533	AE-1B
Sony	KVX2542	AE1C
Sony	KVX2542A	AE
Sony	KVX2545	AE1C
Sony	KVX2552	AE1C
Sony	KV-X2553	AE-1C
Sony	KVX2560	AE2
Sony	KVX2561	AE2
Sony	KVX2561D	AE2
Sony	KVX2561K	AE2
Sony	KVX2562	AE2
Sony	KVX2562U	AE2
Sony	KVX2563	AE2
Sony	KVX2563E	AE2
Sony	KVX257	AE2B
Sony	KVX2572	AE2B
Sony	KVX2573	AE2B
Sony	KVX2582	BE3B

Sony	KVX2582U	BE3B
Sony	KVX25TU	AE1
Sony	KVX28WS1	BE3B
Sony	KVX2902	BE3B
Sony	KVX2903	BE3B
Sony	KVX2910	AE-1
Sony	KVX2931	AE-1B
Sony	KVX2932	AE1B
Sony	KVX2933	AE-1B
Sony	KVX2942	AE1C
Sony	KVX2952	AE1C
Sony	KVX2962	AE2
Sony	KVX2963	AE2
Sony	KVX297	AE2B
Sony	KVX2972	AE2B
Sony	KVX2973	AE2B
Sony	KVX2982	BE3B
Sony	KVX2982U	BE3B
Sony	KX14CP1	
Sony	KX20PS1	HF
Sony	KX-20RSI	
Sony	KX27PS1	HF
Sony	PVM-1440QM	SCC-C57A-A
Sony	PVM-1442QM	SCC-C56A-A
Sony	PVM-1444QM	SCC-C55A-A
Sony	TV9-90UB	D/S MONO
Susumu	FX1400R	Murphy CTV3500
Susumu	FX14S	Murphy CTV3500
Susumu	FX20	Nikkai NT20
Susumu	GT20	Hinari CT5
Tandy	CTV1402	Decca 140
Tandy	CTV1601	Decca 160
Tandy	CTV2102	Decca 160
Tashiko	12D971	Samsung VT306K
Tashiko	14D961	Sanyo CTP3141
Tashiko	14D962	Sanyo E2
Tashiko	14D971	Samsung CI338F
Tashiko	14E881	Nikkai TLG0101
Tashiko	14F891	Decca 160
Tashiko	16E891	Decca 160
Tashiko	20E911	Jackson 20R
Tashiko	20E912	Jackson 20R
Tashiko	20F862	ITT Pico S/3
Tashiko	45E881	Nikkai TLG010
Tashiko	51E941	Finlandia/Salora/Granada
Tashiko	51E942	Finlandia/Salora/Granada
Tatung	DP8655	160
Tatung	RR5188	170Q
Tatung	TN1201	120/130
Tatung	TN1401	140
Tatung	TN1441	140
Tatung	TN1601A	160
Tatung	TN1616	160
Tatung	TN1621	160
Tatung	TN8402	140

Tatung	TN8422	145A
Tatung	TN8432	145
Tatung	TN8904	190
Tatung	TN9201	120/130
Tatung	TNC50	C SERIES
Tatung	TNC52	C SERIES
Tatung	TO8632	165
Tatung	TO8682	165
Tatung	TP1207	120/130
Tatung	TP1403	10
Tatung	TP1603/A	160
Tatung	TP1623	160
Tatung	TP8404	140
Tatung	TP8424	145A
Tatung	TP8434	145
Tatung	TP9207	120/130
Tatung	TP9424	145A
Tatung	TP9434	145
Tatung	TT1202	120/130
Tatung	TT1405	140
Tatung	TT1409	140
Tatung	TT1605	160
Tatung	TT1607	160
Tatung	TT1625	160
Tatung	TT1627	160
Tatung	TT1905	190
Tatung	TT8406	140
Tatung	TT8409	140
Tatung	TT8416	145A
Tatung	TT8426	145A
Tatung	TT8436	145
Tatung	TT8906	190/195
Tatung	TT9202	120/130
Tatung	TT9205	120/130
Tatung	TT9206	120/130
Tatung	TT9406	140
Tatung	TT9409	140
Tatung	TT9416	145A
Tatung	TT9426	145A
Tatung	TT9436	145
Tatung	TU3D53	D SERIES
Tatung	TU8620M	165
Tatung	TU8638	165
Tatung	TU9711	170
Tatung	TUV2C52	C SERIES
Tatung	TUV3A51	A SERIES
Tatung	TUV9705	170
Tatung	TUV9731	170
Tatung	TUV9734	170
Tatung	TV1203	120/130
Tatung	TV1301	120/130
Tatung	TV1303	120/130
Tatung	TV1407	140
Tatung	TV1410	140
Tatung	TV8408	140

Tatung	TV8410	140
Tatung	TV8418	145A
Tatung	TV8428	145A
Tatung	TV9201	120/130
Tatung	TV9203	120/130
Tatung	TV9305	120/130
Tatung	TV9306	120/130
Tatung	TV9308	120/130
Tatung	TV9408	140
Tatung	TV9410	140
Tatung	TV9418	145A
Tatung	TV9428	145A
Tatung	TV9501	150
Tatung	TVC563	Goodmans GTV371
Tatung	TX1302	120/130
Tatung	TX9302	120/130
Tatung	TYS9824	180
Tatung	TYV9821M	180
Tatung	TZ9307	120/130
Tatung	TZ9308	120/130
Tatung	VN1671	160
Tatung	VU3DF3	D SERIES
Tatung	VUV2CC2	C SERIES
Telefunken	417	ICC4
Telefunken	517	ICC5
Telefunken	518	ICC5
Telefunken	617	ICC5
Telefunken	618	ICC5
Telefunken	638	Decca 80
Telefunken	418A	IKC2
Telefunken	418A1	IKC2
Telefunken	517-2	ICC5
Telefunken	617-2	ICC5
Telefunken	618A	ICC5
Telefunken	618B	ICC5
Telefunken	F19	IKC2
Telefunken	F20	IKC2
Telefunken	MP142	IKC2
Telefunken	MR141	ICC4
Telefunken	SN252	IKC2
Thomson	10MG73B	Ferguson TX91
Thomson	28WS23U	ICC17
Thomson	32W583KP	ICC19
Thorn	3788	Ferguson TX10
Thorn	37140	Ferguson TX90
Thorn	38020	Thorn 1790
Thorn	38030	Thorn 1790
Thorn	CT5141	Daewoo CP365
Thorn	P1465R	Decca 190
Thorn	P1480R	Daewoo C901
Thorn	P1482T	Tatung D
Toshiba	2563	
Toshiba	1400TBT	
Toshiba	1400TBZ	
Toshiba	140E4B	

Toshiba	140R3B	
Toshiba	140R4B	
Toshiba	141E3B	
Toshiba	143R4BR	
Toshiba	1440RB	C4
Toshiba	1440TB	C4
Toshiba	1450TB	C4ER
Toshiba	145E7B	
Toshiba	145R7B	
Toshiba	150R6B	
Toshiba	1510RB	
Toshiba	1510TBT	
Toshiba	155R8B	
Toshiba	155R9B	
Toshiba	156R9B	
Toshiba	159X4Y	
Toshiba	1720RB	
Toshiba	1721TB	
Toshiba	1722TB	C4
Toshiba	1752TB	C4ER
Toshiba	175R9B	
Toshiba	175T9B	
Toshiba	199R4B	
Toshiba	201T4B	
Toshiba	202R5B	
Toshiba	202T5B	
Toshiba	2100RBT	
Toshiba	2100TBT	
Toshiba	2101TB	
Toshiba	2102TB	
Toshiba	2103TB	
Toshiba	210R6B	
Toshiba	210T6B	
Toshiba	2112DB	C5 Chassis
Toshiba	211T4B	
Toshiba	212R4B	
Toshiba	212T4B	
Toshiba	2132DB	C3 Chassis
Toshiba	213R4B	
Toshiba	2140RB	C4
Toshiba	2140TB	C4
Toshiba	2141RB	C4
Toshiba	2141TB	C4
Toshiba	2145DB	C3 Chassis
Toshiba	214E7B	
Toshiba	214T7B	
Toshiba	2151TB	C4ER
Toshiba	2152DB	C5 Chassis
Toshiba	215R8B	
Toshiba	215T8B	
Toshiba	2163DB	C6S Chassis
Toshiba	216T9B	
Toshiba	217D9B	
Toshiba	218D9B	
Toshiba	219T9B	

Toshiba	221E4B	Matsui 2220
Toshiba	221T3B	
Toshiba	222T5B	
Toshiba	223B1	Matsui CTV8510
Toshiba	2500TB	
Toshiba	2505DB	
Toshiba	2512DBT	C5 Chassis
Toshiba	251T4B	
Toshiba	2527DB	C2D Chassis
Toshiba	2535DB	
Toshiba	2539DB	C2D Chassis
Toshiba	2545DB	C3 Chassis
Toshiba	2552DB	C5 Chassis
Toshiba	2555DB	C5 Chassis
Toshiba	255R7B	
Toshiba	255T7B	
Toshiba	258T7B	
Toshiba	259D9B	
Toshiba	2805DBT	
Toshiba	2812DB	C91SB Chassis
Toshiba	2835DB	
Toshiba	284T8B	
Toshiba	2852DB	C5 Chassis
Toshiba	2855DB	C5 Chassis
Toshiba	2857DB	C5 Chassis
Toshiba	2857DD	C5SS
Toshiba	285T5BZ	
Toshiba	285T8B	
Toshiba	289T6B	
Toshiba	28W8DB	C7SS Chassis
Toshiba	2927DB	C2D Chassis
Toshiba	2939DB	C2D Chassis
Toshiba	3327DB	C2D Chassis
Toshiba	3339DB	C2D Chassis
Toshiba	3357DB	C5 Chassis
Toshiba	40PW8DB	C8SS Chassis
Toshiba	40PW8DG	C8SS Chassis
Toshiba	56PW8DB	C8SS Chassis
Toshiba	56PW8DG	C8SS Chassis
Toshiba	C1400RB	
Toshiba	C1401B	
Toshiba	C1406	
Toshiba	C1410	
Toshiba	C1695	RANK-T24
Toshiba	C2020	
Toshiba	C2036B	
Toshiba	C2085	RANK-T24
Toshiba	C2090	RANK-T24
Toshiba	C2095B	Bush T24
Toshiba	C2220	
Toshiba	C2225	RANK-T24
Toshiba	C2226	RANK-T24
Toshiba	C2290	RANK-T24
Toshiba	C2295B1	RANK-T24
Toshiba	C2625	RANK-T24

Toshiba	C2625B1	RANK-T24
Toshiba	C2636	
Toshiba	C400BB	
Toshiba	C800	
Toshiba	CT5100	
Triumph	CTV8205	Amstrad CTV1600
Triumph	CTV8208	Amstrad CTV1409
Triumph	CTV8209	Jackson Mk 2
Triumph	CTV8212	Orion CTV144
Triumph	CTV8312	Orion CTV164
Triumph	TC1670	Hitachi NP8CQ
Ultra	2001	Ferguson TX90
Ultra	2201	Ferguson TX100
Ultra	6771	Ferguson TX9
Watson	FA5139	Goodmans 11AK19-8
Zanussi	16ZB312	BS665
Zanussi	16ZT505	BS465
Zanussi	16ZT506	BS565
Zanussi	20ZA374	BS665
Zanussi	20ZA374-16B	BS700
Zanussi	20ZT505	BS465
Zanussi	20ZT506	BS565
Zanussi	20ZT509	BS500
Zanussi	22ZA374	BS665
Zanussi	22ZA377	BS665
Zanussi	22ZA577	BS665
Zanussi	22ZC454	BS665
Zanussi	22ZT505	BS400
Zanussi	22ZT506	BS500
Zanussi	22ZT507	BS400
Zanussi	22ZT616	BS500
Zanussi	22ZT905	BS400
Zanussi	22ZT906	BS500
Zanussi	22ZT907	BS400
Zanussi	26ZA374	BS665
Zanussi	26ZT905	BS400
Zanussi	26ZT906	BS500